
1E40F ENGINE EXPLOSIVE VIEW



1E40F ENGINE PARTS LIST

NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.	NO.	Part No.	Part Name	Qty.
1	1E36FE.9-3	Screw	1	25	GB9074.4	Screw M5×30	4	49	1E40F-HS.3	Guide Cover Ass'y	1	73	1E34F.1-1	Filter Net	1
2	1E36FE.9-4	Ratchet	1	26		MAGNETO ROTOR COMP.	1	50	L6 (LD)	Spark Plug	1	74	1E40F-HS.1-1	Cleaner Outside Cover	1
3	1E36FE.9-1	Starter Rope Reel	1	27	GB/T859	WasherB	1	51	1E40F-3A.8-2	Spring	1	75	1E34F.1.2	Screw	1
4	1E36FE.9-5	Starter Rope	1	28	GB/T97.1	WasherB	1	52	1E34F.5-3	Plug Cap	1	76	1E40F-5A-4	Stand	1
5	1E36FE.9-7	Recoil Spring	1	29	GB6170	Nut M8	1	53	1E34F.5-2	Cap	1	77	1E40F-5A-2	Rubber Cover	1
6	1E36FE.9-8	Starter Cover Ass'y	1	30		IGNITION COIL COMP.	1	54	1E40F-5.3-1	Plug	1	78	1E34F.9.2-3	Cleaner Cover	1
7	GB9074.4	Screw M5×20	5	31	1E40F-5.3.1	Cord Comp.	1	55	1E40F-HS-2	Cover	1	79	1E36FE.10.1-2	Fuel Pipe	1
8	1E40FP-3Z.4-2	Start Handle	1	32	GB9074.13	Bolt M5×20	2	56	1E40F-HS-1	Gasket	1	80	1E36FF.8.1-1	Plug	1
9	1E40FP-3Z.4-10	Ring	1	33	1E36F-3	WasherB	2	57	1E40F-HS.2	Muffler	1	81	1E36FE.10.1-1	Fuel Pipe	1
10	1E36FE.9-6	Spring	1	34	1E40F-5.6-1	Spring	1	58	GB9074.4	Screw M5×12	4	82	GB/T9074.4	Screw M5×16	2
11	1E36FE.9-2	Start pole	2	35	1E40F-5.6.1	Expander	2	59	1E40F-5-13	Bolt	2	83	1E40F-HS.5.1	Fuel Tank	1
12	1E36FE.9	Starter	1	36	1E40F-5-11	Washer	2	60	GB6177.1	Nut M5	2	84	1E32FL.6.2-4	Chain	1
13	1E40F-5-10	Gasket	1	37	1E40F-5-12	Screw Pin	2	61	1E40F-HS.4	Muffler Cover	1	85	1E32FL.6.2-3	End Cover	1
14	1E36FE.7	Start Reel	1	38	1E36F-2-8	Fan Cover	1	62	1E40F-5-2	Gasket	2	86	1E32FL.6.2-2	Inside Cover	1
15	1E36F.2	Oil-seal	2	39	1E40F-3A.9	Clip	1	63	1E40F-5A.2	Admitting Pipe	1	87	EB-415.4.1.1-1	Inlet	1
16	1E40F-5.8-2	Crank Case	1	40	GB9074.13	Screw M5×25	2	64	1E40F-5A-1	Gasket	1	88	CG420.1.3.1-2	Gasket	1
17	1E40F-5.8-4	Gasket	1	41	1E40F-5.4-2	Bearing	1	65	1E40F-5A.8	Carburetor	1	89	1E32FL.6.2-1	Fuel Tank Lid	1
18	GB/T276	Bearing 6202/P5	2	42	1E40F-03.02.01	Ring	2	66	1E34F.1-2	Choker Handle	1	90	1E32FL.6.2	Lid Ass'y	1
19	1E40F-5.4.1	Crank Shaft	1	43	1E40F-5.4-1	Piston	1	67	1E34F.1-7	Stop ring	1	91	1E40F-5A-3	Rubber washer	2
20	GB1099	Key 3x5x13	1	44	1E46FP.6-3	Piston Pin	1	68	GB/T6170	Nut M4	1	92	1E40F-5A.3	Stand	1
21	GB119	Pin B5×10	2	45	1E40FP-3Z.3-5	Piston Ring	2	69	1E34F.1.1	Cleaner inside cover	1	93	GB9074.13	Screw M5×30	2
22	1E40F-5.8-1	Crank Case	1	46	1E40F-5-6	Gasket	1	70	GB/T9074.4	Screw M5x50	2	94	1E40F-HS-3	Label	1
23	1E40F-5.8-3	Guide Cover	1	47	1E40F-5-4	Cylinder	1	71	1E34F.1-3	Choker	1	95			
24	GB119	Pin B4×10	2	48	GB/T70.1	Screw M5×18	4	72	GB/T845	Screw ST4.2X12	1	96			