KM0408003 – RA 895055




制图：　　审核：　　VERSION: 20150609

SN	DESCRIPTION	DOB. ŠIFRA	QTY.
01	CLUTCH DRUM	0408003-M1	1
02	BEARING 6301RS	0408003-M2	2
03	GEAR BOX PART A	0408003-M3	1
04	AXIS A	0408003-M4	1
05	PIN 5X10	0408003-M5	2
06	GASKET	0408003-M9	1
07	GEAR BOX PART B	0408003-M7	1
08	BEARING 6201RS	0408003-M8	3
09	GASKET	0408003-M9	1
10	CIRCLIP	0408003-M10	2
11	GEAR A	0408003-M11/12	1
12	AXLE	0408003-M11/12	1
13	PIN 5X12	0408003-M13	2
14	GEAR BOX PART C	0408003-M14	1
15	SCREW M5X45	0408003-M15	4
16	BEARING 6004	0408003-M16	1
17	CIRCLIP	0408003-M17	1
18	OIL SEAL	0408003-M18	1
19	WASHER	0408003-M19	1
20	CUSHION	0408003-M20	1
21	WAVE WASHER	0408003-M21	5
22	PLAT WASHER	0408003-M22	5
23	SCREW M6X25	0408003-M23	5
24	SCREW M5X25	0408003-M24	2
25	PIN	0408003-M25	2
26	SCREW M5X30	0408003-M26	2
27	AXIS B	0408003-M27/28	1

SN	DESCRIPTION	DOB. ŠIFRA	QTY.
28	GEAR B	0408003-M27/28	1
29	PLAT WASHER	0408003-M29	1
30	SCREW M6X15	0408003-M30	1
31	GEAR BOX ASSY	0408003-SET1	1
32	LATCH	0408003-M32/33	1
33	COTTER	0408003-M32/33	1
34	DRILL	0408003-M34	1
35	THROTTLE	0408003-M35	1
36	SCREW M5X30	0408003-M36	2
37	STOP SWITCH	0408003-M37	1
38	CABLE	0408003-M38	1
39	BELLOWS	0408003-M39	1
40	RUBBER HANDLE A	0408003-M40	1
41	TRIGGER	0408003-M41	1
42	HANDLE PROTECTION	0408003-M42	1
43	TORSIONAL SPRING	0408003-M43	1
44	PLASTIC LATCH	0408003-M44	1
45	SPRING	0408003-M45	1
46	SPRING SEAT	0408003-M46	1
47	SQUARE NUT	0408003-M47	2
48	CIRCLIP	0408003-M48	1
49	FRAME	0408003-M49	1
50	RUBBER HANDLE B	0408003-M50	1
51	PLAT WASHER	0408003-M51	2
52	SCREW M12X15	0408003-M52	2
53	FRAME ASSY	0408003-M53	1
54	SCREW M6X20	0408003-M54	4

KM0408003 - RA 895055 ASSEMBLY DRAWING OF ENGINE 1E48F



NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.	NO.	PART NO.	PART NAME	QTY.
1		Screw	1	29	E0408003-29	PISTON	1	57		Inside Cover	1
2	E0408003-1/6 air filter assy.	Cleaner Outside Cover	1	30		RING	1	58	E0408003-60	Inlet	1
3		Filter Net	1	31		PISTON PIN	1	59		Gasket	1
4	E0408003-3 filter only	Screw M5×50	2	32		Bearing	1	60		Fuel Tank Lid	1
5		Baffle (thickness 1.5mm)	1	33		Crank Shaft Ass'y	2	61		Screw M5×16	2
6		Cleaner inside cover	1	34		KEY 3×13	1	62		Clapboard	1
7	E0408003-7	Carburetor	1	35		Pin 4h8×10	2	63		Crank Case	1
8	E0408003-8	Gasket	1	36	E0408003-36	Gasket	1	64	E0408003-64	Clutch	1
9		Screw M5×30	2	37		Bearing 6202/P6	2	65		Washer 6	1
10	E0408003-10	Admitting Pipe	1	38		Crank Case	1	66		Washer 6	1
11	E0408003-8	Gasket	1	39		Seal	2	67		Bolt	1
12	E0408003-12	Cap	1	40		Screw M5×30	4	68		Screw M5×16	1
13		Spring	1	41	E0408003-41	Coil	1				
14		Plug	1	42		Cord Comp.	1				
15		Screw M5×20	10	43	E0408003-43	Fly Wheel	1				
16		Gasket	1	44		Washer 10	1				
17	E0408003-17	Guide Cover Ass'y	1	45		Washer 10	1				
18		Screw M5×12	1	46		Nut M10×1.25	1				
19		Clapboard	2	47	E0408003-47	Starter	1				
20	E0408003-8	Gasket	1	48		Filter	1				
21	E0408003-21	Muffler	1	49		Fuel pipe 3×1.25×260	1				
22		Washer 8	2	50		Plug	1				
23		Screw M8×30-10.9	2	51	E0408003-53	Fuel pipe 3×1×90	1				
24		Screw M5×12	1	52		Screw M5×25	1				
25	E0408003-25	Cylinder	1	53		Fuel Tank	1				
26	E0408003-26	Gasket	1	54		Gasket	3				
27		Piston Ring	1	55	E0408003-60	Chain	1				
28		Piston Ring	1	56		Cover	1				