RA 698042

EXPLOSIVE VIEW OF KM040716SD



SPARE PARTS LIST OF KM040716SD PAGE:1

NO.	Fig.NO.	PART NO.	DESCRIPTION	QTY
1	KM040716SD-1		ROCKER CAP	1
2	KM040716SD-2		ROCKER	1
3	KM040716SD-3		WASHER Ø10.5*Ø20*1	1
4	KM040716SD-4		COTTER Ø2.5*16	1
5	KM040716SD-5		TUBE CLAMP SET	1
6	KM040716SD-6		CONNECTING ROD	1
7	KM040716SD-7		COTTER Ø2.0*16	1
8	KM040716SD-8		KNOB	1
9	KM040716SD-9		SPEED CONTROL	1
10	KM040716SD-10		PLASTIC PISTON	1
11	KM040716SD-11		SEALING PLASTIC NUT	1

SPARE PARTS LIST OF KM040716SD PAGE:2				
NO.	Fig.NO.	PART NO.	DESCRIPTION	QTY
12	KM040716SD-12		PRESSURE CAP	1
13	KM040716SD-13		SEALING RING	1
14	KM040716SD-14		GLASS BALL	2
15	KM040716SD-15		SEALING CUP	1
16	KM040716SD-16		BALL PEDESTAL	2
17	KM040716SD-17		PLASTIC CYLINDER	1
18	KM040716SD-18		O RING	1
19	KM040716SD-19		SWITCH	1
20	KM040716SD-20		PLASTIC CLIP	1
21	KM040716SD-21		PROTECTIVE SLEEVE	4
22	KM040716SD-22		PUMP	1
23	KM040716SD-23		FLAT HEAD SCREW ST3.8*8	1
24	KM040716SD-24		BACK PROTECTOR	1
25	KM040716SD-25		TANK	1
26	KM040716SD-26		TANK CAP	1
27	KM040716SD-27		FILTER SCREEN	1
28	KM040716SD-28		INDICATER	1
29	KM040716SD-29		CHARGER PORT	1
30	KM040716SD-30		CLAMP	1
31	KM040716SD-31		CIRCLIP	3
32	KM040716SD-32		INPUT PIPE	1
33	KM040716SD-33		SCREW ST4.0*16	4
34	KM040716SD-34		OUTPUT PIPE	1
35	KM040716SD-35		CONNECTING PIPE	2
36	KM040716SD-36		CHARGER	1
37	KM040716SD-37		STRAP	2
38	KM040716SD-38		OUTLET	1
39	KM040716SD-39		BATTERY	1
40	KM040716SD-40		BATTERY FIXER	2

SPARE PARTS LIST OF KM040716SD PAGE:3				
NO.	Fig.NO.	PART NO.	DESCRIPTION	QTY
41	KM040716SD-41		SCREW ST3.8*20	4
42	KM040716SD-42		NOZZEL 1	1
43	KM040716SD-43		NOZZEL 2	1
44	KM040716SD-44		NOZZEL 3	1
45	KM040716SD-45		NOZZEL 4	1
46	KM040716SD-46		NOZZEL 5	1
47	KM040716SD-47		WASHER	2
48	KM040716SD-48		PIPE 1	1
49	KM040716SD-49		O RING	2
50	KM040716SD-50		BATTERY COVER	1
51	KM040716SD-51		SCREW ST3.8*14	7
52	KM040716SD-52		HOSE	1
53	KM040716SD-53		PIPE 2	1
54	KM040716SD-54		HANDLE SWITCH	1
55	KM040716SD-55		INNER FILTER	1