


CODE	Descriptions	type	QTY
1	Nut	M8*1	1
2	Flywheel		1
3	Key	3*10	1
4	Oil seal-right	12*22*5	1
5	Bearing	6001/P5	2
6	Screw	M5*20	4
7	Cylinder seat		1
8	Oil seal-big	12*28*6	1
9	Crankshaft		1
10	Washer		2
11	Piston bearing	KBK081109	1
12	Piston		1
13	Piston clip		2
14	Piston pin		1
15	Piston ring		1
16	Leading wire		1
17	Screw	M4*20	2
18	Spring washer	4	2
19	Washer	4	2
20	Ignition coil		1
21	Ignition coil block	Φ11*Φ4.3*5	2
22	Spark plug	LD L8RTF	1
23	Cylinder		1
24	Inlet pipe		1
25	Screw	M4*14	4
26	Muffler gasket		1
27	Muffler		1
28	Muffler cover		1
29	Spring washer	5	2
30	Screw	M5*45	2
31	Screw	ST3.9*14F	2
32	Top cover		1
33	Gasket		1
34	Ground wire		1
35	Screw	M5*18	4
36	Screw	M5*14	1
37	Back pipe		1
38	Fuel pipe		1
39	Fuel pipe seat		1
40	Fuel filter		1
41	Balancer assy		1
42	Balancer seat		1
43	Screw	ST3.9*16F	8
44	Wood guide		1
45	Fuel cap		2
46	Washer		2
47	Element		2
48	Oil bubble		1
49	Fuel tank		1
50	Oil tank valve		1
51	Sponge		1
52	Clip		1
53	Chain catcher		1
54	Sponge for cover		1
55	Plate cover		1
56	Screw	ST4.2*12.5F	2
57	Damper		2
58	Damper screw		4
59	Damper cover		3
60	Hook		1
61	Screw	ST3.9*12F	4
62	Cover		1
63	Trigger pin	Φ5*28	1
64	Hand shank		1
65	Choke rod damper		1
66	Choke rod		1
67	Throttle interlock arm		1
68	Trigger spring		1
69	Trigger		1
70	On-off switch		1
71	Rear handle cover		1
72	Throttle rod		1
73	Bar protector		1
74	Chain		1
75	Guide bar		1

CODE	Descriptions	type	QTY
76	Spike bumper		1
77	Lining ring		1
78	Carburetor		1
79	Air filter seat		1
80	Air fitler cover		1
81	Screw	M5*45	2
82	Air filter sponge		1
83	Sponge cover		1
84	Air fitler cover		1
85	Knob gasket		1
86	Knob		1
87	Front guard		1
88	Heavy bob		1
89	Bob spring		1
90	Nut	M5	1
91	Brake spring		1
92	Guide pin jacket		1
93	Front hand jacket	Φ6.3*Φ5*22	1
94	Screw	M5*30	1
95	Nut	M8	1
96	Screw	M5*16	1
97	Clutch cover		1
98	Brake band		1
99	Brake spring		1
100	Brake spring arm		1
101	Brake lever-sub		1
102	Lever pin-1	P 3*8.8	2
103	Lever pin-2	P 3*13.8	1
104	Brake lever-main		1
105	Tensioned plate		1
106	Tensioned pin		1
107	Screw	ST3.9*10F	6
108	Tensioned bolt		1
109	Tensioned screw		1
110	Spring		1
111	Spring cover		1
112	Brake spring cover		1
113	Clutch spring		2
114	Clutch block		3
115	Clutch bracket		1
116	Clutch washer	Φ8*Φ32*1.5	1
117	Clutch drum		1
118	Clutch bearing	HK101313	1
119	Worm gear		1
120	Washer	Φ10*Φ18*1.5	1
121	Oil pump cover		1
122	Oil pump		1
123	Oil pump pipe		1
124	Sponge		1
125	Oil pipe	ST4.8*14F	1
126	Oil fiter	Φ5.2*Φ16*1	1
127	Air intake tower		1
128	Fan cover		1
129	Screw		2
130	Washer		1
131	Reel		1
132	Start spring cover	ST4.8*16F	1
133	Start spring		1
134	Start cover		1
135	Front handle		1
136	Screw	Φ2.5*850	2
137	Start knob damper seat		2
138	Damper spring		1
139	Start knob		1
140	Roop		1
141	Insert		1
142	Damper(A)		1
ZC1	Cylinder set		1
ZC2	Fuel cap assy		2
ZC3	Starter assy		1
ZC4	Clutch assy		1
ZC5	Brake assy		1